



0.4 hp. Mini-Dynaflex II

Model: 15002, 15003, 15006, 15013

Repair Tools:

50971 Lock Ring Tool (Exhaust Cover)

96232 Arbor Press (#2)

96240 Bearing Press Tool (02649 Bearing)

96242 Bearing Press Tool (02696 Bearing)

96346 Bearing Separator (2")

96393 Throttle Body Socket (Rear Exhaust, 7° Throttle Body)

96399 Service Tool (Air Inlet)

96460 Wrench (Throttle Body Lock Ring)

96461 Repair Collar (7° Motor Housing)